

neue Artikelnummer	alte Artikelnummer	neue Artikelnummer	alte Artikelnummer
<i>Hebelzylinder ø 24 mm</i>		<i>Rundzylinder außen, System ABUS</i>	
456-H24	456-02-24	456-A	456-28,0-01
W456-H24	W456-02-24	W456-A	W456-28,0-01
V456-H24	V456-02-24	V456-A	V456-28,0-01
J456-H24	J456-02-24	J456-A	J456-28,0-01
356-H24	356-02-24	356-A	356-28,0-01
W356-H24	W356-02-24	W356-A	W356-28,0-01
V356-H24	V356-02-24	V356-A	V356-28,0-01
J456-H24	J356-02-24	J356-A	J356-28,0-01
<i>Hebelzylinder ø 18 mm</i>		<i>Schließeinsatz innen, für RZ-Set System ABUS 1</i>	
J456-H18	J456-02-19	392-A01	392-8-01
J356-H18	J356-02-19	W392-A01	W392-8-01
<i>Möbelzylinder</i>		V392-A01	V392-8-01
456-MZ	640	<i>Rundzylinder-Set System ABUS 1 (A+A01)</i>	
W456-MZ	W640	356-A1	356-28,0-02
V456-MZ	V640	W356-A1	W356-28,0-02
356-MZ	630	V356-A1	V356-28,0-02
W356-MZ	W630	<i>Schließeinsatz innen, für RZ-Set System ABUS 2</i>	
V356-MZ	V630	392-A02	392-8-02
<i>Oval-Halbzylinder, Riegelschloß</i>		W392-A02	W392-8-02
457-RS	457-3	V392-A02	V392-8-02
W457-RS	W457-3	<i>Rundzylinder-Set System ABUS 2 (A+A02)</i>	
V457-RS	V457-3	356-A2	356-28,0-03
J457-RS	J457-3	W356-A2	W356-28,0-03
357-RS	357-3	V356-A2	V356-28,0-03
W357-RS	W357-3	<i>Rundzylinder System W1</i>	
V357-RS	V357-3	456-W1	456-30-01
J357-RS	J357-3	W456-W1	W456-30-01
<i>Oval-Halbzylinder, Riegelschloß 5mm verl.</i>		V456-W1	V456-30-01
457-RS	457-4	356-W1	356-30-01
W457-RS	W457-4	W356-W1	W356-30-01
V457-RS	V457-4	V356-W1	V356-30-01
J457-RS	J457-4	<i>Schließeinsatz System Me</i>	
357-RS	357-4	456-ME	456-26-01
W357-RS	W357-4	W456-ME	W456-26-01
V357-RS	V357-4	V456-ME	V456-26-01
J357-RS	J357-4	356-ME	356-26-01
<i>Oval-Doppelzylinder, Riegelschloß</i>		W356-ME	W356-26-01
417-RS	417-3	V356-ME	V356-26-01
W417-RS	W417-3	<i>Rundzylinder-Set System B1</i>	
V417-RS	V417-3	456-B1	456-06-AB
J417-RS	J417-3	W456-B1	W456-06-AB
317-RS	317-3	V456-B1	V456-06-AB
W317-RS	W317-3	356-B1	356-06-AB
V317-RS	V317-3	W356-B1	W356-06-AB
J317-RS	J317-3	V356-B1	V356-06-AB

neue Artikelnummer	alte Artikelnummer	neue Artikelnummer	alte Artikelnummer
<i>Rundzylinder außen für System Y</i>		<i>Rundzylinder außen, System I1</i>	
456-Y01	456-29,6-08	456-I1	456-29,0-01
W456-Y01	W456-29,6-08	W456-I1	W456-29,0-01
V456-Y01	V456-29,6-08	V456-I1	V456-29,0-01
356-Y01	356-29,6-08	J456-I1	J456-29,0-01
W356-Y01	W356-29,6-08	356-I1	356-29,0-01
V356-Y01	V356-29,6-08	W356-I1	W356-29,0-01
<i>Rundzylinder innen für System Y</i>		V356-I1	V356-29,0-01
456-Y02	456-29,6-07	J356-I1	J356-29,0-01
W456-Y02	W456-29,6-07	<i>Rundzylinder innen, System I2</i>	
V456-Y02	V456-29,6-07	456-I2	456-29,0-02
356-Y02	356-29,6-07	W456-I2	W456-29,0-02
W356-Y02	W356-29,6-07	V456-I2	V456-29,0-02
V356-Y02	V356-29,6-07	356-I2	356-29,0-02
<i>Rundzylinder-Set System Y (Y01 + Y02)</i>		W356-I2	W356-29,0-02
456-Y	456-29,6-10	V356-I2	V356-29,0-02
W456-Y	W456-29,6-10	<i>Rundzylinder-Set System I (I1 + I2)</i>	
V456-Y	V456-29,6-10	456-I	456-29,0-03
356-Y	356-29,6-10	V456-I	V456-29,0-03
W356-Y	W356-29,6-10	W456-I	W456-29,0-03
V356-Y	V356-29,6-10	356-I	356-29,0-03
<i>Rundzylinder außen für System L</i>		V356-I	V356-29,0-03
456-L01	456-29,6-14	W356-I	W356-29,0-03
W456-L01	W456-29,6-14	<i>Rundzylinder innen, System I3</i>	
V456-L01	V456-29,6-14	456-I3	456-29,0-05
356-L01	356-29,6-14	W456-I3	W456-29,0-05
W356-L01	W356-29,6-14	V456-I3	V456-29,0-05
V356-L01	V356-29,6-14	356-I3	356-29,0-05
<i>Rundzylinder innen für System L</i>		W356-I3	W356-29,0-05
456-L02	456-29,6-02	V356-I3	V356-29,0-05
W456-L02	W456-29,6-02		
V456-L02	V456-29,6-02		
356-L02	356-29,6-02		
W356-L02	W356-29,6-02		
V356-L02	V356-29,6-02		
<i>Rundzylinder-Set System L (L01 + L02)</i>			
456-L	456-29,6-11		
W456-L	W456-29,6-11		
V456-L	V456-29,6-11		
356-L	356-29,6-11		
W356-L	W356-29,6-11		
V356-L	V356-29,6-11		